


VIEW SHOWING SIGHT



INTERMEDIATE SIGNALLING LIGHT 0558/462-4417 — FIG 3.6