



TYPE 686M

TRANSMIT RECEIVER UNIT 7AW





TYPE 686M
TRANSMITTER AND RECEIVER
INTERIOR VIEW




METHOD OF ERECTING AERIALS.

DIRECTION OF TRANSMISSION
WHEN ARRAY IS USED.



PLAN.
SECTIONAL VIEW OF CLAMP

EITHER POSITION (1) OR (2) CAN BE
USED FOR FITTING OF DIPOLE OR
ARRAY
POSITION (2) IS TO BE PREFERRED.



TYPE 686, AERIALS
SINGLE DIPOLE

5
6




FIG. 5

4-ELEMENT UNIDIRECTIONAL ARRAY

