

RECEIVER H.F. M.F. AP 100335
I.F. AND A.F. UNITS LAYOUT AND SWITCH WIRING DIAGRAM
(SHEET 2)

NOTE 2: IF TR301 IS REPLACED IT IS IMPORTANT TO READ THE NOTE ON PAGE 81