SECTION J VALVES

SUB-SECTION J A RECEIVING VALVES NR

3 ELECTRODE VALVES

4 " " JA 2

TEST BOARD FOR D.E. VALVES " JA 3

VALVE TEST BOARD FOR WIT RACK" " JA 4


SUB-SECTION J B TRANSMITTING VALVES NT GLASS VALVES PAGE JB2
SILICA " JB4

SUB-SECTION J C RECTIFYING VALVES NU.

GLASS VALVES PAGE JC 2

SILICA " JC 2

RECEIVING VALVES NR. 3 ELECTRODE BATTERY HEATED VALVES.



4 ELECTRODE VALVES







3 ELECTRODE.

NAME	FILAMENT		ANODE		MUTUAL	A. C. RESISTANO	CE AMPLIFI-	TYPE OF FITTING	CLASS
OF VALVE,	VOLTS	AMPERES	VOLTS	CURRENT (Ma)	CONDUCT- ANCE. (gm)	OHMS (rg)	FACTOR.		FILA- MENT.
NR4 NR4C NR7 NR12A NR13 NR13A NR14 NR15 NR16 NR16 NR16 NR16 NR16 NR16 NR16 NR17	3.6	0.8 0.8 0.65 0.65 0.65 0.65 0.115 (max) 0.12 (max) 0.085-0.105 0.25 (max) 0.25 (max) 1	50	0.77 0.77 0.77 0.77 1.07 0.57 1.07 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.57 1.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0 0.0	0.7 1.2-2.4 0.9 1.3-2.6	30000 to 600 100000 (max) 5000 to 80 1850 to 38	000	Screw Screw Clip Clip 4 pin Inter Service Clip 4 pin 5 pin 5 pin 5 pin	Bright Bright Bright Bright Bright Bright Dull Dull Dull Dull Dull Dull Dull Dul

NOTE - NR7A is gettered, NR7 is not.

4 ELECTRODE (DULL EMITTER).

NAME	FILAMENT		ANODE .			A. C. RESISTANCE	AMPLIFI- CATION	TYPE OF FITTING	SCREEN VOLTS.
VALVE.	VOLTS	AMPERES	VOLTS	CURRENT (Ma)	CONDUCT- ANCE. (gm)	OHMS (r _a)	FACTOR.		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
NR19 NR22 NR23	3.6 3.6 3.6	0.3 0.07-0.11 0.07-0.11	100 100	2 2	0.35 0.6 0.6-1.8	150000 300000 167000 - 360000	70 260 130-360	Double-ended 4 pin with Anode terminal. 4 pin with Anode terminal.	

TEST BOARD FOR DULL EMITTER VALVES (PATTERN 1248).

This Test Board is supplied to enable gradual failure of a valve due to loss of emission to be observed. (There are three known causes of loss of emission (a) Excessive filament volts, (b) Excessive anode volts, (c) Continuous running on too low a filament voltage). There are two fittings, one for four pin valves (1) and one for clip in valves (2). The voltmeter is a pattern 5526 used on the 25 volt range as a milliammeter connected to terminals (3) and (4). The 4 volt and 50 volt supplies are from the ordinary receiving batteries via terminals (7)(8) and (5)(6) respectively. With this arrangement the emission of each valve can be measured under standard conditions — i.e. constant supply of 4 volts L.T., 50 volts H.T., and grid connected to negative filament. In the case of screen grid valves NR22 and NR23 the screen grid is used as the anode, and the anode is left disconnected. The following table gives the minimum values of the voltmeter reading for various valves when the full scale reading is 25 volts:—

VALVE	VOLTMETER READING.				
NR14	1				
NR17	1				
NR15	1.4				
NR15A	1.5				
NR16	11,0				
NR16A	12.0				
NR22	1. 75				
NR23	1. 75				


ALLOWANCE OF RECEIVING VALVES.

The number of receiving valves allowed to a ship is based on the total number of receiving valve sockets in a ship.

Bright Emitter first 15 sockets 5 valves per socket.

remainder 3 valves per socket.

Dull Emitter first 10 sockets 3 valves per socket. remainder 2 valves per socket.



VALVE TEST BOARD FOR W/T RACK.

Date of design:-

This toard is supplied to enable the ship's staff to carry out periodical tests on receiving valves in order to detect loss of emission. The circuit diagram is shown in Figure a. Deterioration in valves takes the form of increase in A.C. resistance and decrease in mutual conductance.

With this board the mutual conductance and A. C. resistance values for triodes, and the mutual conductance values for screen grid valves can be measured.

The board is fitted with a holder for valves of the NR14 type (17) and a standard 5-pin valve holder (16). There is also a terminal (18) for connection to the anodes of screen grid

The 100 volt (1) and 4 volt (2)(3) tattery supplies should be connected to the battery terminals through the rack switch and the condition of the ratteries can be checked by means of the dual range voltmeter (6).

To measure filament voltage the voltmeter switch (7) must be in the filament position (14) and for anode voltage the switch must be in the anode position (13). The main switch (15) must be in any of the "ON" positions.

The anode voltage can be varied by means of a potentiometer (4) in series with a fixed resistance (8) retween H. T. positive and L. T. negative and is equal to the supply voltage when the potentiometer is set to its maximum position.

When the main switch (15) is in position Triode 1 or 2, the variable H.T. potential is applied to the anode terminals of the valve holders (16) and (17). When the switch is in position SGV 1 or 2 the variable potential is applied only to the SGV anode terminal (18) and the valve holders anode terminals are connected to the junction of the potentiometer (4) and the fixed resistance (5).

The anode current of the valve under test is measured by means of the dual range milliammeter (9). The switch (11) has two positions (10) and (12) for readings of 0 - 100 milliamps and 0 - 10 milliamps.

A fixed potentiometer (19) is connected across the L.T. supply for applying grid bias to the grid terminals.

There are two tappings (20) and (21) on the potentiometer - one to be used when the L. T. supply is from a 4-volt tattery, and the other in the case of 2 volt supply.

When the main switch (15) is moved from position Triode 1 to Triode 2, or from SSV1 to SGV2, the grid tias is altered from 0 to + 0.5 volts.

Triodes with directly heated filaments.

Method of test - Measurement of A. C. resistance.

To carry out the tests, the main switch is to be put to position Triode 1 and the anode current is to be measured first with an anode voltage of 70 volts and then with an anode voltage of 80 volts. The difference between these readings should be greater than the minimum difference given for each type of valve.

Valve type.	Minimum difference of anode currents.
NR14	0.15 milliamp.
NR17	0.15
NR15	0.4
NR 15A	O, 7 "
NR16	20 ⁿ
NR16A	20 "

Triodes with indirectly heated filaments.

Method of test - Measurement of mutual conductance.

To carry out this test, the anode voltage should be 96 volts and the anode current is to te measured first with the main switch in position Triode 1 and then with the switch in position Triode 2. The difference between the two readings should be greater than the minimum difference for each type of valve.

Valve type.		Minimum	difference	of anode	currents.
NR26	\$1970 auduR\$	CONTRACTOR OF THE PARTY OF	0.6	milliamp.	
NR27		1 10	1.0	7 7	
NR31	R STALL	PJ 54	0.8	W.	第一、第一次

Screen Grid Valves.

Method of test - Measurement of mutual conductance.

To carry out this test, the anode of the valve under test is to be connected to the SSV anode terminal (18) and the H.T. potentiometer (4) set to give an H.T. voltage of 96 volts. anode current is measured first with the switch in position SSV1 and then with the switch in position SGV2. The difference between the two readings should be greater than the minimum difference for each type of valve.

. Minimum difference of anode currents. Valve type. O. 25 milliamp. NR22

In all cases the filament voltage is not to be less than 3.6 volts.

VALVE TEST BOARD .




FIG. a.




FIG. b.